



ASSEMBLY INSTRUCTIONS



▶ Scan QR code for
installation video



For assembly assistance,
✉ support@yfs.life 🌐 yfs.life/sdk9011

English

Caution

- Before you begin: Lay out all parts on a clean surface to check if the tags and numbers are correct.
- Please use the screws correctly, otherwise you might damage the desk panel.
- Don't screw tightly before all the screws are put into the corresponding holes.
- Please make sure the product has been installed correctly and read the instructions before using the product.
- Do not use corrosive or abrasive materials to clean this product.
- The company does not bear any warranty or liability for damage and human injury caused by any abnormal or un-intended operation of the equipment.

Français

Attention

- Avant de commencer l'installation, disposez toutes les pièces sur une surface propre pour vérifier si les étiquettes et les numéros correspondent.
- Veuillez utiliser correctement les vis. Sinon, le plateau de la table pourrait être endommagé.
- Toutes les vis ne doivent pas être vissées trop fermement avant d'être placées dans les trous correspondants.
- Veuillez vous assurer que le produit a été installé correctement et lire attentivement les instructions avant d'utiliser le produit.
- N'utilisez pas de matériaux corrosifs ou abrasifs pour nettoyer ce produit.
- La société n'assume aucune garantie ou responsabilité pour les dommages et les blessures humaines causés par un fonctionnement anormal ou involontaire de l'équipement.

Italiano

Attenzione

- Prima di iniziare l'assemblaggio, disporre tutti i componenti su una superficie pulita per verificare che le marcature e i numeri corrispondano.
- Utilizzare correttamente le viti. In caso contrario, il piano del tavolo potrebbe subire dei danni.
- Tutte le viti non devono essere serrate eccessivamente prima di inserirle negli appositi fori.
- Assicurarsi che il prodotto sia stato assemblato correttamente e leggere attentamente le istruzioni prima di utilizzarlo.
- Non utilizzare materiali corrosivi o abrasivi per pulire il prodotto.
- L'azienda non garantisce né si assume la responsabilità per eventuali danni o lesioni causati da un funzionamento anormale o involontario del prodotto.

Deutsch

Vorsicht

- Bevor Sie mit dem Aufbau beginnen, legen Sie alle Teile auf einer sauberen Oberfläche aus, um zu prüfen, ob die Kennzeichnungen und Nummern übereinstimmen.
- Bitte verwenden Sie die Schrauben richtig. Andernfalls könnte die Tischplatte beschädigt werden.
- Alle Schrauben sollten nicht zu fest angezogen werden, bevor sie in die entsprechenden Löcher gesteckt werden.
- Vergewissern Sie sich, dass das Produkt korrekt aufgebaut wurde, und lesen Sie die Anweisungen sorgfältig durch, bevor Sie das Produkt verwenden.
- Verwenden Sie keine ätzenden oder scheuernden Materialien zur Reinigung dieses Produkts.
- Das Unternehmen übernimmt keine Garantie oder Haftung für Schäden und Verletzungen, die durch einen abnormalen oder unbeabsichtigten Betrieb des Geräts verursacht werden.

Español

Precaución

- Antes de comenzar la instalación, extienda todas las piezas sobre una superficie limpia para comprobar si las etiquetas y los números se corresponden.
- Por favor, utilice correctamente los tornillos. De lo contrario, el tablero de la mesa podría resultar dañado.
- Todos los tornillos no deben atornillarse con demasiada fuerza antes de introducirlos en los agujeros correspondientes.
- Por favor, asegúrese de que el producto ha sido instalado correctamente y lea atentamente las instrucciones antes de utilizarlo.
- No utilice materiales corrosivos o abrasivos para limpiar este producto.
- La empresa no garantiza ni se responsabiliza de los daños y perjuicios causados por un funcionamiento anormal del producto o se causado accidentalmente por el producto.



English Important

- Before you begin: Lay out all parts on a clean surface to check if the tags and numbers are correct.
- Don't screw tightly before all the screws are put into the corresponding holes.
- Please use the screws correctly. Otherwise, you might damage the tabletop.

Français Important

- Avant de commencer: Disposez toutes les pièces sur une surface propre pour vérifier si les étiquettes et les numéros sont corrects.
- Ne vissez pas fermement avant que toutes les vis soient mises dans les trous correspondants.
- Veuillez utiliser les vis correctement. Sinon, vous risquez d'endommager le plateau de la table.

Italiano Importante

- Prima di iniziare: Disporre tutte le parti su una superficie pulita per verificare se le etichette e i numeri sono corretti.
- Non avvitare saldamente prima che tutte le viti siano inserite nei fori corrispondenti.
- Si prega di utilizzare le viti correttamente. Altrimenti, si potrebbe danneggiare il piano del tavolo.

Deutsch Wichtig

- Bevor Sie beginnen: Legen Sie alle Teile auf einer sauberen Oberfläche aus, um zu prüfen, ob die Kennzeichnungen und Nummern korrekt sind.
- Schrauben Sie nicht fest, bevor nicht alle Schrauben in die entsprechenden Löcher eingedreht sind.
- Bitte verwenden Sie die Schrauben richtig. Andernfalls könnten Sie die Tischplatte beschädigen.

Español Importante

- Antes de empezar: Coloque todas las piezas sobre una superficie limpia para comprobar si las etiquetas y los números son correctos.
- No atornille firmemente antes de colocar todos los tornillos en los orificios correspondientes.
- Por favor, utilice los tornillos correctamente. De lo contrario, podría dañar el tablero del escritorio.



EN Assembly Guide

Scan the QR code for installation videos and detailed user instructions.

DE Installationsanleitung

Scannen Sie den QR-Code, um Installationsvideos und weitere Anleitungen zu erhalten!

FR Guide d'assemblage


Scannez le code QR pour obtenir des vidéos d'installation et des instructions d'utilisation détaillées.

ES Guía para el montaje

Escanee el código QR para ver videos de instalación e instrucciones detalladas de uso.


IT Guida al montaggio

Scansiona il codice QR per vedere i video di installazione e le istruzioni dettagliate per l'uso.




Select Return Configuration

Option 1




Page 6-14


Option 2




Page 15-23




Complete through collaboration.




Assemble on a protective surface to prevent scratches.




Phillips screwdriver or drill required (not provided).




Allow an assembly area at least twice the desktop size.




①x1




②x1




③x1




④x1



⑤x1




⑥x1



⑦x6



⑧x1




⑨x1



⑩x4



⑪x4



⑫x1




M6x12

Ax24




ST4x16

Bx2




M6x30

Cx29




Dx1




Ex1

Option 1




Page 6-14

1





2





Note: This manual only contains instructions for tabletop installation. To complete the full desk setup, please refer to the separate manual for the frame installation.

**ASSEMBLY
INSTRUCTIONS**




4





TEAM LIFT

WARNING. Danger of injury.
We recommend two to three people to complete the flipping of the desk.




5







6




7




8




9




10




11




12



13




Need to use matching screws for self tapping.




14



Tip: Raise desk to maximum height for easy screw installation.






Instructions for Use of Socket

Safety Warnings


- Do not overload the power outlets. Ensure the total power consumption does not exceed 1500W of the outlets.
- Avoid using the desk in humid environments to prevent electric shock or short circuits.
- Regularly inspect the power cords and outlets. If any damage is found (e.g., cracks, looseness, or burn marks), stop using the product immediately and contact a professional for repair or replacement.
- Do not unplug an electrical appliance by pulling its flexible power cord. Otherwise, it may damage the wire connection and cause danger.
- Do not spill food or liquids on the outlets.
- Place the desk where children cannot easily access the power outlets.
- Use childproof outlet covers to prevent accidental contact by children.
- Educate children not to climb on or pull the desk to avoid accidents.

Option 2




Page 15-23

1



2





3



Note: This manual only contains instructions for tabletop installation. To complete the full desk setup, please refer to the separate manual for the frame installation.


ASSEMBLY INSTRUCTIONS




4




WARNING. Danger of injury.
We recommend two to three
people to complete the flipping
of the desk.




5







6




7




8




9




10





11





12



13




i **Need to use matching screws for self tapping.**




14



Tip: Raise desk to maximum height for easy screw installation.



15




Instructions for Use of Socket

Safety Warnings

- Do not overload the power outlets. Ensure the total power consumption does not exceed 1500W of the outlets.
- Avoid using the desk in humid environments to prevent electric shock or short circuits.
- Regularly inspect the power cords and outlets. If any damage is found (e.g., cracks, looseness, or burn marks), stop using the product immediately and contact a professional for repair or replacement.
- Do not unplug an electrical appliance by pulling its flexible power cord. Otherwise, it may damage the wire connection and cause danger.
- Do not spill food or liquids on the outlets.
- Place the desk where children cannot easily access the power outlets.
- Use childproof outlet covers to prevent accidental contact by children.
- Educate children not to climb on or pull the desk to avoid accidents.


Handheld Remote Control and LED Strip Light

Remote Control Parameters



Use Handheld Remote Control

1. Use handheld remote control for on/off control and color control.
2. Remove plastic tab from battery door before use. To replace remote control's battery, follow directions on the back of remote control to slide battery drawer out.
3. Replace battery (+ sideup) and slide battery drawers back in place. Ensure a direct line of sight from the remote to the receiver (located at the start of the tape light) for optimal use.
4. Maximum effective remote distance: 15 to 20m (49 to 65 ft).





WARNING


- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
A swallowed button cell or coin battery can cause **Internal Chemical**
- **Burns** in as little as 2 hours.
- **KEEP** new and used batteries OUT OF REACH of CHILDREN
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- The battery type used in the product is CR2025, and the battery voltage is 3V.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 40°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Care and Maintenance

1. Before attempting to clean the rope light, unplug the adapter from the power outlet.
2. To clean the rope light, use a clean, dry, or slightly damp cloth.
3. Do not use any cleaners with chemicals, solvents, or harsh abrasives, as damage to the rope light may occur.
4. Allow the light strip and components to dry thoroughly before plugging the power adapter back into the power outlet.



Important Safety Instructions



1. USB 5V 1A.
2. Do not submerge the neon flex light in liquids or use the product in the vicinity of standing water or other liquids.
3. Do not secure this product with staples, nails, or other sharp objects that may damage the insulation.
4. Do not cover this product as the covering may cause the flexible light to overheat and either melt or ignite.
5. Do not use if there is any damage to the light or cord insulation. Inspect periodically.



1. To avoid possible fire, product damage, or early lamp failure, this neon flex light should not be used in heat-producing appliances.
2. Do not operate neon flex light while coiled.
3. Do not install the neon flex light within 2.9m/9.5ft of the pool or spa.
4. Do not route the cord or flexible light cable through walls, doors, windows, or any similar part of a building or structure.
5. Do not subject flexible lighting to continuous flexing.
6. Do not install near or around flammable or corrosive materials.

Troubleshooting

1. The adhesive tape is not strong enough.
 - Make sure the installation surface is clean and dry.
 - Firmly press over the light after sticking.
 - Reinforce the installation via more clips and screws.
 - Move the control box closer to the music source.
2. Cannot sync the tape light up to the beat of my music.
 - Clean the microphone on the control box and then try again.
 - Ensure microphone is facing outward and is unobstructed.
3. The light does not respond to the remote control.
 - Ensure the IR receiver is within line-of-sight of the remote control.
 - Ensure the plastic pull tab has been removed from the remote.
 - Try moving closer to the receiver.



FR

Cet appareil se recycle

REPRISE
À LA LIVRAISON

OU

À DÉPOSER
EN MAGASIN

OU

À DÉPOSER
EN DÉCHÈTERIE

Points de collecte sur www.quefairedemesdechets.fr
Privilégiez la réparation ou le don de votre appareil !